

AT27Q-SB Cleaning Maintenance Guide



Basic Care & Maintenance

Dust and other foreign matter on the clear plate of the reading window can impede code input, thus it is recommended to clean this on a regular basis.

- To clean the plate, first blow the dust away with an airbrush. Then, gently wipe the plate with a cotton swab or a soft lint-free cloth.
- If sand or hard particles have accumulated, never rub the plate; doing so will scratch or damage it. Blow the particles away with an airbrush or a soft brush first.

Care & Maintenance with alcohol disinfectant and washing soap



1. Wet a soft lint-free cloth with our approved disinfectant or washing soap (see below).
2. Gently wipe product body and reading window.
3. Ensure to completely wipe away all disinfectant or washing soap residue on product body and the reading window.

【Caution】

- Do NOT dip into or directly spray onto the product body any liquid or cleaning solution.
- Do not soak disinfectant, washing soap or humidity into the product.
- In the event of any white or yellow discoloration, stop using disinfectant and washing soap immediately.

Approved Disinfectant and Washing Soap

We have confirmed that we have not see any appearance, function and performance damage on product based on wipe-away testing done once a day.

- Sani-Cloth® Plus Germicidal Wipes [PDI]
- Sani-Cloth® HB Germicidal Wipes [PDI]
- Sani-Cloth® PDI AF3 Wipes [PDI]
- Disinfecting Wipes (Bleach-free)[Clorox]
- Formula 409 Multi-Surface [Clorox]
- CaviWipesXL Disinfecting Towelettes [Metrex]
- Cidex OPA Solution [Advanced Sterization Products]
- Hepacide Quat II [Spartan]
- Windex original Spray [SC Johnson]

